

Operation of the Bluetooth remote control and battery

Pair the remote control to the mobile dust extractor (without Bluetooth battery pack)



Set the switch on the mobile dust extractor to AUTO. Press the green pair button on the mobile dust extractor for 3 seconds until a quickly rotating blue light appears. The dust extractor will be in pairing mode for 60 seconds.



Briefly press the large button [MAN] on the top of the remote control once. The mobile dust extractor is now paired.

Disconnect the remote control from the mobile dust extractor:

- ▶ Then simultaneously press both green buttons on the remote control until a magenta light on the remote control appears. The remote control is then disconnected.

Pair the cordless power tool to the mobile dust extractor (with Bluetooth battery pack)



Set the switch on the mobile dust extractor to AUTO. Briefly press the green pair button on the mobile dust extractor until a rotating blue light appears. The dust extractor will be in pairing mode for 60 seconds.



Switch on the power tool with the Bluetooth battery pack. The mobile dust extractor is now paired to the tool.

Disconnect the battery pack from the mobile dust extractor:

- ▶ Turn off the mobile dust extractor (Set the switch to 0 position)
- ▶ Disconnect the mains plug of the mobile dust extractor
- ▶ Insert the Bluetooth battery pack into the charger

Pair the cordless power tool to the mobile dust extractor using the remote control.



Briefly press the small green pair button on the front of the remote control until a rotating blue light appears around the authorization button on the mobile dust extractor. The dust extractor will be in pairing mode for 60 seconds.



Switch on the power tool with the Bluetooth battery pack. The mobile dust extractor is now paired to the tool.

Disconnect the battery pack from the mobile dust extractor:

- ▶ Turn off the mobile dust extractor (Set the switch to 0 position)
- ▶ Disconnect the mains plug of the mobile dust extractor
- ▶ Insert the Bluetooth battery pack into the charger

NOTE:

- ▶ No more than five remote controls can be paired to one mobile dust extractor.
- ▶ A remote control can only be connected to one mobile dust extractor. The remote control can only be paired with another mobile dust extractor once it has been disconnected to the first.
- ▶ Only one battery pack at a time and no more than five remote controls can be paired simultaneously to one mobile dust extractor.

When the max. number of devices is reached, then the device that has not been used for the longest time is deleted.



FESTOOL

www.festool.com/bluetooth



FESTOOL

www.festool.com/bluetooth